


# HS-934SU BOARD



CN201	
1	+5.2V
2	+5.2V
3	GND
4	+3.3V
5	E=5V
6	GND
7	GND
8	P-CONT
9	AU+12V
10	AU GND
11	AU-12V
12	-10V
13	GND
14	MTR +12V
15	MTR GND

MB-83 BOARD (11/16)  
CN001 (SEE PAGE 4-39)

MB-83 BOARD (11/16)  
CN002 (SEE PAGE 4-39)

no mark : E-E mode